

**INSTALLATION, OPERATION and
MAINTENANCE MANUAL**

**Direct Acting
Pressure Reducing Valve
Model: RE 1**



MIYAWAKI INC.

Osaka, Japan

The MIYAWAKI-Pressure Reducing Valve RE 1 is a direct acting pressure regulator designed for use in steam lines.

Prior to using the RE 1, read this manual thoroughly to understand the correct handling and operating procedure.


The manual should be used by experienced personnel as a guide to the installation and maintenance of the RE 1.

We ask you to contact MIYAWAKI or its local representative if further information is required.

1. Technical Data

Max. Primary (Inlet) Pressure:	RE1: 16 bar, 1600 kPa, 230 psig RE1-4 : 10 bar, 1000 kPa, 145 psig RE1-2 : 10 bar, 1000 kPa, 145 psig
Max. Secondary (Outlet) Pressure:	RE1: 10 bar, 1000 kPa, 145 psig RE1-4: 4 bar, 400kPa, 58 psig RE1-2: 2 bar, 200 kPa, 29 psig
Min. Secondary (Outlet) Pressure:	RE1, RE1-4: 0,5 bar, 50 kPa, 7 psig RE1-2: 0,2 bar, 20 kPa, 3 psig
Max. Pressure Reducing Ratio:	10:1
Max. Operating Temperature:	204°C, 400°F


2. Dimensions



Type	Size	Connection	Dimensions (mm)				Dimensions (in)				Weight	
			L	H ₁	H ₂	W	L	H ₁	H ₂	W	kg	lb
RE1	1/2"	Screwed Rc, NPT	80	137	46	63	3.2	5.4	1.8	2.5	1,4	3.1
RE1-4	3/4"		90				3.5				1,5	3.3
RE1-2	1"		105	144	58		4.1	5.7	2.3		1,9	4.2


3. Installation

- 3.1. The pressure reducing valve should be installed in a horizontal pipe with the handle turned upwards.
- 3.2. The length of the straight section of the upstream piping and the length of the straight section of the downstream piping should be each at least 10 pipe diameters.
- 3.3. The pressure reducing valve should be protected with a strainer. The strainer should be installed in such a way that the screen will point sideways to avoid the accumulation of condensate in the area of the screen.
- 3.4. To prevent water hammer and vibrations caused by incoming condensate it is necessary to install a steam trap before the pressure reducing valve.
- 3.5. Select the size of the pressure reducing valve according to the real operating conditions. Don't use a too large pressure reducing valve.
- 3.6. It is recommended to install a manometer, a stop valve and a strainer upstream and a manometer, stop valve and safety valve downstream.
- 3.7. If you will use a motor valve or solenoid valve downstream (dead end service), install a steam trap between the pressure reducing valve and these valves to prevent water hammer or misfunctions at the time of start-up.



4. Adjustment of the RE 1

- 4.1. After the installation and before the adjustment of the pressure reducing valve close the stop valves before and behind the pressure reducing valve and open the bypass to remove all condensate and dirt from the pipe.
- 4.2. Close the bypass valve and pull the green handle while the stop valves are closed. Turn the handle clockwise until the handle will touch the cover.
- 4.3. Open the stop valve downstream slightly. Then open the stop valve upstream slowly.
- 4.4. Pull out the handle again and turn it counterclockwise until the required pressure is attained.
- 4.5. Release the handle so that it will engage.
- 4.6. Now, open the stop valve downstream completely and check again the setted pressure.
- 4.7. In case of a shut-down of the equipment the stop valve downstream must be closed at first. The stop valve upstream is to be closed as a second step. When the equipment will start up again open the stop valve downstream at first and than open the stop valve upstream slowly.



5. Maintenance

5.1. Replacement of Valve and Valve Seat


- a) Unfasten the body plug (3) and take out the screen (17) ; then remove the spring (16) and the valve (4).
- b) Unscrew the valve seat (5).
Take out the gasket (21) .
- c) Replace the gasket (21) and fasten the valve seat (5) .
(spanner size: 24 mm; torque: 600 kgf·cm)
- d) Put the valve (4) on the spring (16) and insert it into the screen (17). Replace the gasket (20) and fasten the body plug (3) .
(spanner size: 30mm; torque: 800 kgfcm)

5.2. Cleaning up the screen

- a) Unfasten the body plug (3) and take the screen (17) out (same as 5.1.a)
- b) Clean up the screen (17).
- c) Assemble in the same way as .5.1.d).

5.3. Replacement of the bellow

- a) Pull out the handle of the RE 1 (10) and turn it clockwise until stopping. Unfasten the cover (2) (spanner size: 58 mm) and remove the spring (8), the bellow and holder (6 & 7).
- b) Replace the gaskets 22 and 23 . Put the new bellow unit into the body (1) and put the spring (8) on the holder (7). Now fasten the cover again.
(torque: 1200 kgf·cm)



CAUTION ! Never open the pressure reducing valve when under pressure.

6. Trouble shooting

A. The downstream pressure doesn't meet the set value:

Possible cause

- a. Pressure was set incorrectly.
- b. Wrong selection of the PRV.
- c. The upstream stop valve is closed.

- d. The inlet pressure is lower than the set outlet pressure.
- e. The steam supply is lower than the downstream steam consumption.
- f. The screen is plugged.

Solution

- a. Check and set again.
- b. Check and select again.
- c. Open the upstream stop valve.

- d. Check and correct.
- e. Check and correct.
- f. Clean up the screen according to 5.2.

B. The downstream pressure is higher than the set value:

Possible cause

- a. Wrong setting.
- b. Wrong selection of the PRV.

- c. The downstream stop valve is closed.
- d. The steam consumption is lower than the smallest possible steam flow.
- e. The bypass - stop valve is open.
- f. Dirt between valve and valve seat; damaged valve or valve seat.
- g. Damaged bellow unit .

Solution


- a. Check and set again.
- b. Check and select again.

- c. Open the stop valve.
- d. Check and select a new PRV.
- e. Close the stop valve.
- f. Clean or replace the parts.

- g. Replace according to 5.3.

7. Valve details

Parts-No.	Name
1	Body
2	Cover
3	Plug
4	Valve
5	Valve seat
6	Bellows
7	Holder
8	Spring
9	Sleeve
10	Handle
11	Orifice plate
12	Shaft
14	Adjust bolt
15	Bush
16	Spring
17	Screen
24	Name plate



MIYAWAKI Inc.
 2-1-30, Tagawakita
 Yodogawa-ku
 Osaka 532-0021
 Japan
 Tel.: +81-6-6302-5549
 Fax: +81-6-63025595
export@miyawaki.net
www.miyawaki.net



MIYAWAKI GmbH
 Birnbaumsmühle 65
 15234 Frankfurt (Oder)
 Germany
 Tel.: +49-335-4007-0097
 Fax: +49-335-4000-122
info@miyawaki.de
www.miyawaki.de